

PRO COMPUTER FUNCTION LIST 2014

Specififaction		SCIO				SX4	DIGI	
		SCIO ALTI ANT+	SCIO ANT+	SCIO ALTI	SCIO	SX4	DIGI 5IVE	DIGI 5IVE(W)
Wireless type	Wire / Wireless	Wireless	Wireless	Wireless	Wireless	Wireless	Wired	Wireless
	Wireless type	ANT+	ANT+	RF (analog)	RF (analog)	Low Frequency Digital	Wired	RF (analog)
	Transmission frequency	2,4 MHz	2,4 MHz	40 KHz	40 KHz	121 KHz	-	40KHz
Speed & Distance	Current speed	x	x	x	x	x	x	x
	Distance	x	x	x	x	x	x	x
	Max speed	x	x	x	x	x		
	Average speed	x	x	x	x	x	x	x
	Odometer	x	x	x	x	x	x	x
Time	Ride time	x	x	x	x	x	x	x
Temperature	Temperature	x	x	x	x			
	Min Temperature	x	x	x	x			
	Max Temperature	x	x	x	x			
Altitude	Current altitude	x		x				
	Current gradient	x		x				
	Average gradient	x		x				
	Total uphill	x		x				
	Total downhill	x		x				
Di2	Di2 gear display	x	x					
	Di2 battery indication	x	x					
Features	Low battery indication	x	x	x	x	x	x	x
	Unit selection	x	x	x	x	x	x	x
	Wheel circumference input	x	x	x	x	x	x	x
	2 Wheel settings	x	x	x	x			
	Auto start / stop	x	x	x	x	x	x	x
	12 / 24 Hours Clock	x	x	x	x	x		
	Speed pacer	x	x	x	x	x	x	x
	Back light	x	x	x	x			